Rigid Lifelines® Traveling Bridge Anchor Track™ System

This guide can be used to prepare a bid specification for the incorporation of a Traveling Bridge Anchor Track System into a competitive bid project or application.

*Each product specification is organized in three standard sections:

SECTION 1 - GENERAL:

Includes product scope, references, performance requirements, applicable documents, quality assurances, product warranty information, and project conditions and handling practices.

SECTION 2 - PRODUCTS:

Includes a description of materials, products, and accessories to be incorporated into the project.

SECTION 3 – EXECUTION:

Includes provisions for product preparation, installation, field quality control, demonstrating and training, and protection.

*The specifier may need to edit this product specification to reflect the options and applications for a specific project. Notes to assist the specifier in editing this product specification are indicated in brackets. All notes and brackets should be deleted on the final draft.

SECTION 1 – GENERAL

1.1 SCOPE

- A. Product: Sold as kit or a custom-engineered system, the Traveling Bridge system provides rigid fall protection and features a trolley that traverses a traveling bridge that glides along two mounted tracks. Tracks are mounted to either the ceiling's existing support beams or freestanding support columns with I-beams. This system is provided with drop-rod type hanger assemblies that include adjustable beam clamps and 12-inch drop rod or with flushmount type hanger assemblies. The drop-rod type hanger assembly requires sway bracing and allows for slopes up to 14 degrees. Freestanding system requires concrete foundations. Multiple bridges allow multiple workers. System offers 360-degree user movement in large buildings that keeps the worker's attachment point always centered overhead—minimizing swing fall hazards.
- B. General Design Standards: System is designed in conformance with the following applicable standards:
 - 1. ANSI Z359, OSHA 1910.66, and AISC Manual of Steel Construction.
- C. Standard Equipment Specifications:
 - 1. Standard Track Length: [Track length is determined by the amount of actual working area needed, the fall hazard, and by the length of the track from one end stop to the other.1
 - Bridge Span: [Bridge span is length of the bridge between the centers of track.]
 - 3. Bridge Length: [Bridge length is the overall length of the bridge.]
 - 4. Coverage Area: [Traveling linear coverage on the x-axis and the y-axis to keep the attachment point directly overhead.]

- 5. Working Capacity: [All standard systems are designed for use with lanyards that limit the maximum average arresting force to 900 pounds. Worker capacity also depends on the number of people using the system at once. For more than two worker access, please contact a Rigid Lifelines Technical Sales Support Specialist.]
- 6. Number of Bridges: [Number of bridges is determined by the number of workers that need to access the system at one time.]
- 7. Overall Height: [The overall height is measured at the highest point on system after installation.1
- 8. Trolley-Hook Height: [The trolley-hook height is measured by the distance from the ground to the underside of the trolley hook.1
- 9. Worker Passability: [Worker passability depends on whether two workers need to pass one another while tied-off to the system. Worker passability also requires a dual track
- 10. Support Centers: [Support centers are determined by the distance from one ceiling support beam to next.]
- 11. Overhang: [Standard track overhangs are up to 18 inches from the center of a hanger location to the end of the trussed track.]
- 12. Construction: [Fabricated using high-strength steel or ASTM A36 steel for structural components.]

1.2 **REFERENCES**

- A. American Institute of Steel Construction (AISC): Manual of Steel Construction
- B. American National Standards Institute (ANSI) ANSI Z359: Fall Protection Code
- C. American Society for Testing and Materials (ASTM) A36: Carbon Structural Steel
- D. American Society for Testing and Materials (ASTM) B221: Aluminum-Alloy Extruded Bar, Rod, Wire, Shape, and Tube
- E. American Society of Automotive Engineer (ASAE) J429: Grade 5
- F. American Welding Society (AWS) D1.1: Structural Welding Code
- G. Occupational Safety and Health Administration (OSHA)—Specification 1910.66: Personal Fall Arrest System

1.3 PERFORMANCE REQUIREMENTS

- A. Coverage: System shall provide rectangular coverage area of size indicated on drawings and consist of:
 - 1. Track bolted on existing structures
 - 2. Track hanger assemblies
 - Swiveling connector Anchor Trolley™
 - 4. Rigid, single or double girder bridge moving perpendicular to track
 - 5. Columns (for Freestanding Traveling Bridge system only)
- B. Modular, pre-engineered design: System shall be designed for one, two, or multiple workers using single, dual, or multiple tracks.
 - 1. System shall be designed, fabricated, and installed in accordance with ANSI Z359, OSHA 1910.66, and AISC Manual of Steel Construction.
- C. Design Strength: For one user, the system shall be designed based on a worst-case placement of the 900-pound (408 kg) maximum average arresting force with a safety factor of two and the weight of the anchor system.
- **D. Operating Temperature:** 5 to 200 degrees F (-15 to 93 C)
- E. Structural Design: The system's structural design is based on dynamic load capacity.

F. System shall be designed to withstand:

- 1. System and dynamic load and impact factors.
- 2. Dynamic load capacity equal to rated capacity.
- 3. Inertia forces from system and dynamic load movement.

1.4 **DOCUMENTS**

A. Submittal Procedures

- 1. Product data is included for the system and all accessories. Product data provides capacities, performance, standard use, and applied forces to system.
- 2. Shop drawings, which outline system configuration, dimensions, construction, and assembly details
- 3. Manufacturer's Warranty
- 4. Manufacturer's Assembly and Operation Instruction Manual with included Assembly **Drawings**

1.5 **QUALITY ASSURANCE**

- A. Standard system shall be designed, fabricated, and installed in accordance with ANSI Z359, OSHA 1910.66, and AISC. Rigid Lifelines® assures the safety and quality of all systems when installed and maintained according to their Assembly and Operation Instruction Manual.
 - 1. Applications where system will be used in potentially hazardous environments or explosive environments require special consideration. These special conditions must be disclosed prior to placing an order.
 - 2. Applications where system will be used in essential facilities, such as fire departments, military buildings, or communications buildings, will require special consideration.
 - 3. Custom systems (systems modified over and above the standard dimensions or capacities shown within our Rigid Lifelines literature) will require special consideration.
- B. If different specifications are required, alternate specifications must be requested before the order is placed. System modifications may be required at additional cost to conform to specifications other than ANSI and OSHA.
- C. Manufacturer's Qualifications: An ISO 9001:2015 registered company with more than 20 years of experience successfully designing and manufacturing fall protection solutions.
- D. Installer's Qualifications: A company that is acceptable to the manufacturer and meets OSHA requirements for a Competent Person assembling and installing fall protection systems for multiple applications. Installer should be able to:
 - 1. Bolt connections in accordance with torque tightening procedures specified in AISC Manual, Part 5.
 - 2. Clearly label system with maximum average arresting force visible from tie-off position.

1.6 WARRANTY

- A. Manufacturer's Warranty: Included on manufacturer's standard form and outlines the manufacturer's agreement to repair or replace assemblies and components that fail in materials and/or execution within warranty period from date of substantial completion.
 - 1. Warranty covers the engineered track equipment, wearable end truck wheels, and Anchor Trolley[™] wheels and teeth to be free from defects in material and workmanship for a period of ten (10) years commencing on the date of shipment from the Rigid Lifelines facility.

1.7 CONDITIONS/DELIVERY, STORAGE, AND HANDLING

A. Project Conditions

- 1. Maintain environmental conditions (temperature, humidity, and ventilation) within limits recommended by manufacturer for optimal results.
- 2. Do not install products under environmental conditions outside manufacturer's absolute limits

B. Delivery, Storage, and Handling

- 1. Store products in manufacturer's packaging until ready for installation.
- 2. Store and dispose of solvent-based materials in accordance with requirements of local authorities.

SECTION 2 - PRODUCT

2.1 **ACCEPTABLE MANUFACTURERS**

A. Rigid Lifelines[®]

Locations: Morgantown, PA and Las Vegas, NV; Phone: 800-869-2080;

Website: RigidLifelines.com

TRAVELING BRIDGE ANCHOR TRACK™ SYSTEM 2.2

*System is available for one, two, or multiple workers.

- A. Models: The following is the Traveling Bridge system manufactured by Rigid Lifelines
 - 1. Ceiling-Mounted Traveling Bridge system as manufactured by Rigid Lifelines.
 - a. Sold as kit or a custom-engineered system, the Ceiling-Mounted Traveling Bridge system provides rigid fall protection and features a trolley that traverses a traveling bridge that glides along two mounted tracks. This system is provided with drop-rod type hanger assemblies that include adjustable beam clamps and 12-inch drop rod or with flush-mount type hanger assemblies. The drop-rod type hanger assembly requires sway bracing and allows for slopes up to 14 degrees. Depending on design specification and dimensions, typical overall weights are approximately between 715 and 1,489 pounds for steel and 665 and 1,476 pounds for aluminum. Standard track lengths are between 23 and 123 feet. Standard bridge lengths are between 12 and 32 feet. Field assembly comes with bolt-together components (no welding required).
 - b. Construction: Fabricated using high strength steel or ASTM A36 steel for structural components.
 - 2. Freestanding Traveling Bridge system as manufactured by Rigid Lifelines.
 - a. Sold as kit or a custom-engineered system, the Freestanding Traveling Bridge system provides rigid fall protection and features a trolley that traverses a traveling bridge that glides along two mounted tracks. Tracks are mounted to freestanding support columns with I-beams. System requires concrete foundations. Field assembly comes with bolt-together components (no welding required).
 - b. Construction: Fabricated using high strength steel or ASTM A36 steel for structural components.
- B. Design Factors: Track, tubing, and welded track has minimum yield strength of 46,000 pounds per square inch. profile design ensures wheel protection, accurate alignment with minimum friction, and low-maintenance, self-cleaning profile. All track shall have full contact flange loading surfaces (flat) to decrease flange and wheel loads during a fall event.
- C. Structure: Enclosed Anchor Track™(s) held by hanger assemblies bolted either to existing structures or freestanding columns with steel I-beams.

- 1. Hanger assemblies: Includes hanger assemblies that provide a rigid connection for suspending tracks. Assembly to consist of angle truss clamps and truss clamp plates. Use of threaded rods in flush hanger assemblies is not permitted.
- 2. Columns: Steel tubing with full bottom base plate and top plate (for freestanding system
- 3. Steel I-beam: Fabricated from singlewide flange beam. Includes clamp plates for attaching I-beam to column.
- 4. Runways: Vertical truss fabricated from square steel tubes and enclosed steel track.
 - a. Track: Enclosed cold-formed steel track that serves as bottom cord of trussed track and permits end trucks to ride on lower inside flanges. Fabricate lower running flanges with flat surface for higher durability and wheel contact. Sloped flanges are not permitted.
 - b. Track splice: Includes truss splice plates and channel-shaped track splice joints for joining track sections. Splice joints must be located within four feet of a support point.
 - c. Standard track overhangs: Up to 18 inches of overhang is allowed from the center of a hanger location to the end of the trussed track. Longer track overhangs are done on a customized basis.
- Enclosed Bridge: Cold formed steel box track that permits Anchor Trolley™ to ride along track's lower inside flanges. Fabricate lower running flanges with flat surfaces. Sloped flanges not permitted.
- 6. End Trucks: Rigid frame end truck designed to ride inside enclosed track and connect to and suspend bridge.
 - a. Construction: Steel fabrication with both vertical and horizontal wheels to prevent binding in track.
 - b. Wheels: Removable, self-centering wheels with sealed lifetime lubricated bearings. Vertical wheels shall be flat to match track profile. Non-removable or non-tapered wheels are not acceptable. Polyamide wheel material is provided by Rigid Lifelines®. Steel wheels are optional.
 - c. Drop Lugs: Included on both sides of truck to limit truck drop in the event of wheel or axle failure.
 - d. Connection to Bridge: Includes a sliding or flexible connection between bridge and end truck. Rigid connections or articulating connections with threaded hardware are not acceptable.
- 7. Swiveling connector Anchor Trolley™: Rigid-body trolley designed to ride inside enclosed track and to carry load.
 - a. Construction: Steel body with two wheels on each side and positioning attachment point at center of trolley so load weight is evenly distributed to trolley wheels.
 - b. Braking system: If at least 80 pounds of force, including the weight of the selfretracting lanyard, are exerted on the swiveling connector, a series of eight hardened-alloy steel contact points create friction against the enclosed track. The friction generated by the contact points, in conjunction with the weight of the worker, causes the trolley to stop all movement on the track.
 - c. Wheels: Removable, self-centering wheels with sealed lifetime lubricated bearings. Vertical wheels shall be flat to match track profile. Non-removable or tapered wheels are not acceptable. Polyamide wheel material is provided standard by Rigid Lifelines[®]. Steel wheels are optional.
 - d. Designed for attachment of carabiner.
- 8. End stops: Molded composite resilient bumper installed in track to prevent the trolley or end trucks from rolling out of track. Bolt stops without energy absorbing bumper are not acceptable.

2.3 SYSTEM OPTIONS

*The following options are available for the Traveling Bridge Anchor Track™ System.

[Select required options from the following, or contact Rigid Lifelines if other types of accessories are required.]

A. Model Types

- 1. Ceiling-Mounted Traveling Bridge system
- 2. Freestanding Traveling Bridge system

B. Application Options

- 1. Multiple bridges for multiple workers with independent movement
- 2. Bridges can be constructed of steel or aluminum
- 3. Flush-cross mounted or flush-parallel mounted to existing structures
- 4. Bar joist and wood joist mount connections
- 5. Beam clamp hangers and drop rods (require sway bracing)
- 6. System available in stainless steel
- 7. Virtually unlimited track lengths
- 8. Anchor Track™ options
 - a. Plain or trussed track (single, dual, triple, or quad trussed track)
 - b. Aluminum Anchor Track: Extruded from high-strength 6061-T6 aluminum alloy
 - c. Steel Track: Rolled from ASTM A572, A607, or A715 grade steel; available with enamel, powder, epoxy, or galvanized coatings
 - d. Stainless steel track: 304 stainless for 500 Series track

2.4 SYSTEM COMPONENTS

- A. End Truck for Enclosed Track System (End trucks provide smooth running connection between traveling bridge and track.)
 - 1. Standard wheels are large diameter polyamide, equipped with anti-friction ball bearings (steel wheels optional).
 - 2. Bronze wheels and quide rollers are available for spark resistant applications.
 - 3. Placement of horizontal steel guide rollers on either end of the truck guards against crabbing of the traveling bridge.

B. Track

- 1. Steel enclosed trussed track allows for greater spans and greater distance between supports.
- 2. Low profile keeps space requirements to a minimum.
- 3. Combination of high strength to low weight ratio reduces stress on structures.

C. Track Hanger Assemblies

- All Traveling Bridge Anchor Track™ Systems are provided with drop-rod type hanger assemblies that include adjustable beam clamps and a 12-inch drop rod or with a flushtype hanger assembly for attachment to ceiling structures or columns.
- 2. Hanger assemblies are of appropriate size and numbers for selected system.

D. Track Splice Assemblies

- 1. Slide track splice over track profile to ensure proper alignment.
- 2. Trussed track splice assembly bolts through top cord to prevent joints from separating.

E. Threaded Drop Rod Hanger Assembly

- 1. Standard hanger assembly for trussed track includes:
 - a. Adjustable beam clamps that provide a secure fit to ceiling structure. Flange widths range from two inches to eight inches.

- b. Standard 12-inch drop rod (longer as required).
- c. Trussed track support brackets.

F. Sway Bracing

- 1. Required on all drop rod supported systems to ensure maximum track rigidity.
- 2. Sway brace clips attach to standard drop rods and track clamps. The sway brace clips fit one-inch diameter schedule 40 pipe at a 45-degree angle.
- 3. One-inch pipe supplied by others.

G. Flush-Cross Mount Hanger Assemblies

- 1. Optional hanger assembly that longitudinally attaches track to ceiling structure.
- 2. Hanger assembly is fabricated from structural plate equipped with Grade 5 bolts and beam clips.

H. Flush-Parallel Mount Hanger Assemblies

- 1. Optional hanger assembly that latitudinally attaches track to ceiling structure.
- 2. Hanger assembly is fabricated from structural plate equipped with Grade 5 bolts and beam clips.

I. End Stops

- 1. End stops are equipped with resilient rubber bumpers to increase impact resistance and are through bolted to the enclosed track.
- 2. End stops are standard on all systems.

J. Swiveling Connector Anchor Trolley™

- 1. The Anchor Trolley is built with non-consumable parts and a fault indicator that appears if an internal spring breaks.
- 2. When at least 80 pounds of force, including the weight of the self-retracting lanyard, are exerted on the swiveling connector, the brakes engage.
- 3. The brakes are composed of a series of eight hardened-alloy steel contact points that create friction against the enclosed track. The friction generated by the contact points, in conjunction with the weight of the worker, causes the trolley to stop on the track.

2.5 **SHOP FINISHING**

A. Standard Paint Colors:

1. All systems are painted with one coat of Rigid Lifelines® Yellow Industrial Enamel.

B. Surface Preparation and Painting Procedures:

- 1. Rigid Lifelines adheres to the standards of the Society for Protective Coatings (SSPC) for all product surface preparation.
- 2. Rigid Lifelines Anchor Track™ System components are deburred and descaled using power tools equipped with sanding discs and wire wheels prior to painting.
- 3. Components are washed with high-pressure/high-temperature biodegradable degreaser solution.
- 4. All components are coated with quick drying semi-gloss enamel applied to a minimum dry-film thickness of two to three mils.
- 5. A finishing coat is applied with a hot airless electrostatic spray paint system.
- 6. Painted components are cured at air temperature.

SECTION 3 – EXECUTION

3.1 PREPARATION

- **A. DO NOT** start assembly until support structures are properly prepared.
- B. Inventory:

1. Check materials to ensure all parts are present.

C. Foundation (only for Freestanding Traveling Bridge system)

- 1. Anchor bolts for support columns are not included. Four, 13/16-inch diameter holes are provided for anchor bolts.
- 2. Check concrete footings, slabs, or other foundations to ensure sufficient system support.
- 3. Ensure accurate anchor bolt patterns are provided for foundation design.

3.2 ASSEMBLY

INOTE: The following installation information is provided only as a reference tool. For complete installation and maintenance instructions, refer to manual 103-0076.]

- A. Units and accessories should be installed in accordance with manufacturer's Assembly and Operation Instructions Manual.
- **B.** Do not modify system components without manufacturer's approval.

C. Installation Manual/Assembly Drawings

- 1. Refer to Price Guide, proposal drawings (if applicable), or approval drawings (if applicable) to find dimensions for a specific model.
- 2. Consult installation manual for list of building materials.

D. Column and I-Beam Installation (for Freestanding system only)

- 1. Arrange installation area, position columns, and verify orientation. Bolt columns to floor and attach I-beam to columns with fasteners.
- 2. Follow the same procedure for subsequent sets of columns and I-beams.

E. Enclosed Track Installation

- 1. Bolt mounting support brackets or hangers to the ceiling beams or to freestanding
- 2. Raise the track and attach it to the brackets or hangers with the appropriate fasteners.
- 3. Standard overhang is 18 inches for trussed track beyond the last support center at either end. Refer to your Final Fabrication
 - Drawing for correct overhang lengths for your specific system.
- F. Track Splice Installation (Application varies depending on required track length and support structure)
 - 1. For systems with more than one section of track, an additional section is installed in the same manner, with the addition of splice joint assembly.
 - 2. The track splice joint is made using a sleeve. Slide sleeve over end of first track, and butt second track against first. Center sleeve over joint. Tighten all top setscrews and side setscrews for correct track alignment. Do not over tighten screws.
 - 3. Track splice joints include two splice plates. Install splice plates to connect ends of truss top tubes. For trussed track, splice joints should be within 48 inches of support hanger.

G. Bridge End Truck Installation

- 1. Insert bridge into end truck sleeves. Locate center of end trucks approximately 12 inches from ends of bridge. One end truck is secured to bridge track with setscrews, and one end truck is allowed to slide freely on bridge track.
- 2. Install bridge by inserting both end trucks into one end of the tracks.
- 3. Adjust and tighten the bridge end truck set screws to minimum clearance of two inches between the ends of the bridge and any side obstructions.
- 4. Adjust support brackets or hangers to minimum clearance of three inches between top of bridge and any overhead obstructions.

H. Bridge Installation

1. Install swiveling connector Anchor Trolley™ on track.

- 2. Secure bridge to tracks with end stop bolts and rubber bumpers.
- 3. Once installation is complete, enclosed tracks should be leveled. Install lateral and longitudinal sway bracing. Check tightness for all bolts and nuts.

Swiveling Connector Anchor Trolley™ Installation

1. Install swiveling connector Anchor Trolley on track. Secure end stop bolts and rubber bumpers.

J. Final Assembly

- 1. Torque locknuts and bolts to appropriate specifications.
- 2. After installation is complete, enclosed tracks should be leveled. Check tightness for all bolts and nuts.
- 3. This system must be used with an ANSI-rated self-retracting lanyard (SRL). Connect SRL and retrieval tagline in accordance with manufacturer's specifications.

3.3 FIELD QUALITY CONTROL

*Perform field quality control inspection before each use, after a fall event, and annually. These checklists are included in the Assembly and Operation Instruction Manual. A Competent or Qualified Person must conduct the annual inspection. Consult the Traveling Bridge Anchor Track™ System Assembly and Operation Instruction Manual for more information.

A. Inspection

- After a Fall Event and Annual Anchor Track™ System Inspection Checklist
 - a. Check that the beam clamps are installed horizontal within + / five degrees.
 - b. Check that end stop bolts are present and have locknuts installed.
 - c. Using a torque wrench, check that all bolts are present and torqued to values shown on Assembly Drawing.
 - d. Check that splices, if supplied, are centered on track joints.
 - e. Verify that capacity labels are present, attached, and legible. See Label Placement Drawing. Verify that the number of trolleys matches the value on the capacity label.
 - f. Verify that the fall arrest system is not being used for material handling.
 - g. Check the track for levelness within + / 1/4 inches per 20 feet of track.
 - h. Check the track flanges. Track flanges cannot be bent downward more than five degrees. Check the track thickness. Track thickness cannot be worn more than 10 percent.
 - i. Check all system welds for cracks.
 - Check system components for corrosion and bent or damaged areas.
 - k. Check that all wheel studs, if supplied, are torqued to value shown on Assembly Drawing. Note that these 1/2-inch wheel studs have a different torque value than the system's other 1/2-inch bolts.
 - Verify trolley can traverse entire length of track without snags.
 - m. Check trolley for visibly bent swiveling connector, broken welds, or excessive wear or corrosion.
 - n. Test the operation of the trolley's swiveling connector and verify that it can rotate freely. Test the operation of the trolley and verify the wheels rotate freely.
 - o. Check system components for loose components.
 - p. Check system components for loose or missing fasteners.
 - q. Check system support structure for stability.
 - r. Verify that hanger assemblies are installed properly and fasteners are torqued to proper values.
 - s. Check that the support arms pivot bolts, if supplied, are properly installed and

tightened. Check system for unauthorized modifications. Only Rigid Lifelines can authorize modifications. Remove system from service if it is modified in any way.

2. Before Each Use Inspection Checklist

- a. Test the swiveling connector(s) on each trolley to verify that each trolley rotates and swivels freely.
- b. Verify that the trolley(s) can easily and smoothly roll the full length of the track(s).
- c. Check all system welds for cracks.
- d. Check system components for corrosion.
- e. Check system components for bent or damaged areas.
- f. Check support structure for stability.
- g. Visually check all bolted assemblies for proper connections and properly secured bolts and nuts.

B. Acceptance Inspection

1. After the system has been installed and after any modifications, an acceptance inspection must be performed using the After a Fall Event and Annual Anchor Track System Inspection Checklist included in the Assembly and Operation Instruction Manual before use. A qualified person or competent person must perform acceptance inspections.

C. Maintenance

- To keep systems in good operating order, engineers recommend establishing a regular schedule of inspection and lubrication. All parts should be inspected, all loose parts adjusted, and worn parts replaced at once.
- Check track splices for alignment, and verify that Anchor Trolley™ travels smoothly through joints.
- 3. A Competent Person must perform an annual system inspection using the After a Fall Event and Annual Anchor Track System Inspection Checklist included in the Assembly and Operation Instruction Manual.

D. Clean Surfaces

- 1. Touch up scratches and blemishes with matching paint from manufacturer.
- 2. Keep surfaces clean and clear of build-up and residue.

E. Protect System

- 1. Protect assembled products until completion of project.
- 2. Touch-up, repair, or replace damaged products before substantial completion.

F. Quality Standards

- 1. Rigid Lifelines[®] is an ISO 9001:2015 Registered Corporation.
- Welding performed during manufacturing process meets the American Welding Society's (AWS) D1.1 Standards.
- Rigid Lifelines Anchor Track™ Systems are manufactured to standards ensuring safety, reliability, and the highest quality.
- 4. Rigid Lifelines' products are manufactured in the United States of America at facilities located in Morgantown, Pennsylvania, and Las Vegas, Nevada.
- 5. Rigid Lifelines certifies that all system components are in full compliance with the Buy American Clause of the American Recovery and Reinvestment Act (ARRA) of May 2009.